

METHOD AND SYSTEM FOR PREDICTING
PHARMACOKINETIC PROPERTIES

5 **CROSS REFERENCE TO RELATED APPLICATION**

This application claims the benefit of U.S. Provisional Application No. 60/211,864 filed June 14, 2000.

Technical Field

10 This invention relates to a method and system to predict pharmacokinetic (ADME) properties such as drug absorption (permeability), distribution, metabolism, and excretion, which are crucial properties in drug discovery.

Background Art

15 Experimental measurements to obtain pharmacokinetic properties are time-consuming and labor-intensive. Moreover experiments require a significant amount of actual compounds. Thus, the computational methods to predict such properties of virtual compounds are highly desirable in prioritization of targets prior to synthesis.

20 So far, similar descriptors as conventionally employed in the quantitative structure activity relationship (QSAR) analysis (steric bulk, lipophilicity, HOMO energy, *etc.*) have been adopted in quantitative structure property relationship (QSPR) analysis to correlate with PK-related parameters ($t_{1/2}$, clearance, or oxidation rate, *etc.*) (Lien, E. J. *et al. Acta Pharm. Jugosl.* **1984**, 34, 123—131; Baeuerhielm, C. *et al. Chem.-Biol. Interact.* **1986**, 58, 277—288). Graph theory derived parameters (molecular connectivity indexes, *etc.*) have been also used for this purpose (Markin, R. S. *et al. Pharm. Res.* **1988**, 5, 201—208; Garcia-March, F. J. *et al. J. Pharm. Pharmacol.* **1995**, 47, 232—236). Recently reported QSPR methods necessitate calculation on 3D-structures that is still computationally intensive (Lombardo, F. *et al. J. Med. Chem.* **1996**, 39, 4750—4755; Palm, K. *et al. J. Med. Chem.* **1998**, 41, 5382—5392; Clark, D. E. *J. Pharm. Sci.* **1999**, 88, 815—821). The QSPR methods also necessitate complete set of molecular parameters (van de Waterbeemd, H. *et al. Quant. Struct.-Act. Relat.* **1996**, 15, 480—490) that require experimental measurements to be determined.

30

2D-fingerprints are frequently employed in molecular similarity/diversity analysis (*e.g.* ISISTM/Base similarity search or SYBYLTM/Selector), high-volume QSAR analysis (*e.g.* HQSAR, *vide infra*), and other drug discovery scenes. To date there has been no report on development of 2D-fingerprints descriptors to analyze pharmacokinetic properties.

WO 98/07107 discloses a MOLECULAR HOLOGRAM QSAR (HQSARTM) to develop high volume QSAR models. HQSARTM uses molecular hologram based on fragments counts to deal with mostly potency/activity. A symposium proceeding (Niwa, T. "Prediction of Human Intestinal Absorption of Drug Based on Neural Network Modeling"; 27th Symposium on Structure-Activity Relationships held in Japan, Nov. 10, 1999) describes a method to estimate human intestinal absorption (HIA) based on molecular topological indexes derived from 2D-structure.

It could be highly desirable to provide a system and method to predict pharmacokinetic properties of actual and virtual molecules with high performance (predictivity and speed) and wide applicability to diverse molecules.

Brief Disclosure of the Invention

This invention provides a new method and system for QSPR analysis and prediction based on only 2D-structure that allows us to predict hundreds of compounds rapidly. The method and system of this invention employs 2D-fingerprints, an array of the counts of functional groups as descriptors for QSPR.

This invention provides a method for predicting pharmacokinetic properties of molecules comprising the steps of:

- (a) preparing 2D-structures of molecules used as a training set;
- (b) constructing a 2D-fingerprint by counting the number of structural descriptors that potentially relate to a pharmacokinetic property, either manually or automatically using internally developed macro; wherein said structural descriptors consist of predefined 20 to 80 atoms/fragments or substructures;
- (c) analyzing the obtained 2D-fingerprint by a statistical analysis method to correlate with the pharmacokinetic property of the molecule to yield a quantitative structure-property relationship (QSPR) model; and

(d) calculating the pharmacokinetic property of a trial molecule using the above obtained QSPR model.

This invention also provides a system for predicting pharmacokinetic properties of molecules comprising:

5 (a) means for preparing 2D-structures of molecules used as a training set;

(b) means for constructing a 2D-fingerprint by counting the number of structural descriptors that potentially relate to a pharmacokinetic property, wherein said structural descriptors consist of predefined 20 to 80 atoms/fragments or substructures;

10 (c) means for analyzing the obtained 2D-fingerprint by a statistical analysis method to correlate with the pharmacokinetic property of the molecule to yield a quantitative structure-property relationship (QSPR) model; and

(d) means for calculating the pharmacokinetic property of a trial molecule using the above obtained QSPR model.

15 Another aspect of this invention provides a method wherein the pharmacokinetic property is absorption.

Another aspect of this invention provides a method wherein the pharmacokinetic property is distribution.

Another aspect of this invention provides a method wherein the pharmacokinetic property is metabolism

20 Another aspect of this invention provides a method wherein the pharmacokinetic property is excretion.

Another aspect of this invention provides a method wherein the internally developed macro comprises the macro script 2dfp.spl or 2dfp_abs.spl, written in SYBYL™ Programming Language (SPL).

25 Preferably, each of the steps of the methods of the invention is carried out using molecular modeling software, databases or drawing software. More preferably one is such as SYBYL™, version 6.5 (Tripos Inc., St. Louis, MO). The database includes, for example, ISIS Base™ version 2.2.1 (MDL information Systems, Inc. San Leandro, CA.). The drawing software includes such as SYBYL™/SKETCH option, ISIS™
30 Draw version 2.2.1, Chem Draw Pro™ version 5.0 (CambridgeSoft. Corp. Cambridge, MA) and SMILES™ (Daylight Chemical Information Systems, Inc., Mission Viejo,

09876757-060701

CA). Other modeling software, databases, and drawing software known to those of skill in the art can also be used.

This invention enables us to perform virtual screening for synthetic targets and data mining using databases as well as drug design to optimize the pharmacokinetic profiles. Based on the QSPR model in this invention, it is possible to predict pharamacokinetic properties of molecules prior to synthesis, without labor-intensive and time-consuming experiment. This invention relies on 2D-fingerprint modeling requiring only 2D-structure, which enables us to perform rapid calculation to predict hundreds of compounds without tedious calculation about 3D-structure. Moreover, 2D-fingerprint used in this invention comprises only 20-80 bits.

Description of Figures

Figure 1 is a flowchart showing the overall process of the invention.

Figure 2 shows a plot of actual vs. calculated $\log t_{1/2}$.

Figure 3 shows a plot of actual vs. calculated $\log(P_{app} * 10^6)$.

Figure 4 shows a plot of actual vs. calculated $\log BB$.

Detailed Disclosure of the Invention

The term "molecules used as a training set" as used herein, refers to the molecules whose pharmacokinetic properties have been already determined experimentally and used to develop a predictive QSPR model.

The term "pharmacokinetic properties" as used herein, refers to the properties of molecules related to metabolism, absorption (permeability), distribution, and excretion (ADME).

A number of experimental methods or models are known in ADME.

Examples of absorption studies are 1) kinetic studies based on measuring plasma concentration, urinary fecal excretions and gastrointestinal disposition after oral administration *in vivo*, 2) single-pass perfusion method, recirculation method, loop method *in situ*, and 3) everted sacs method, methods of using brush border membrane vesicles, isolated cells, and cultured cells (Caco-2) *in vitro* and the like.

Examples of distribution studies are 1) the method of measuring concentration of target organs after administration by various technique such as HPLC, LC-MS,

autoradiography and microdialysis *in vivo*, 2) brain perfusion methods such as vascular reference method (brain uptake index) *in situ*, and 3) methods of using isolated cells or cultured cells (such as endothelial cell) *in vitro* and the like.

5 Examples of metabolism studies are 1) kinetic studies based on measuring concentrations of drugs and the metabolites after adequate administration routes such as intravenous administration, administration per portal vein *in vivo*, and *in situ*, 2) kinetic studies such as a half-life of drugs in mammalian organ (liver, kidney, intestine, etc. with slices, homogenates and microsomes etc) and in isolated cells or cultured cells such as hepatocytes *in vitro* and the like.

10 Examples of excretion studies are 1) kinetic studies based on measuring concentration of drugs in urine, bile, feces etc after administration *in vivo*, 2) enzymatic studies of excretion via pumps such as P-glycoprotein, *in vitro* and the like.

The term "2D-fingerprint" as used herein, refers to a 2D-molecular measure in which a bit in a data string is set corresponding to atoms/fragments or substructures.

15 The term "predefined atoms/fragments or substructures" as used herein, refers to atoms or functional groups relating to a pharmacokinetic property, which are based on the literature source (Bonse, V.G., Metzler, M. "Biotransformationen Organischer Fremdstoffen" (Yakubutu-Taisha) in Japanese Asakura, Tokyo (1980); Kato, R., Kamatani, T. "Yakubutu-Taishagaku" in Japanese, Tokyo-Kagaku-Dojin, Tokyo, chapter 4, 93-123, (1995)), otherwise refers to functional groups such as saturated or unsaturated bonds, rings (aromatic or cycloalkyl), amines, anilines, nitrogen in aromatics, imines/nitriles/guanidine/amidine, oxyamine(N-O)/nitro/azo-/hydrazin, amide/thioamide/sulfonamide/, alcohol/ether/aldehyde/ketone/ester/carboxylic acid/carbothioic acid/sulfinic acid/sulfonic acid, halogen, oxygen or sulfur functional groups, and total number of carbon, hydrogen, nitrogen, oxygen, sulfur or phosphorus atom.

25 The term "internally developed macro" as used herein, refers to an internally developed Sybyl Programming Language (SPL) code. Preferable internally developed macro is as described in Working Examples 4 and 5.

30 The QSPR model based on 2D-fingerprints for metabolism predicts half-life of molecules in a human liver microsome mixture with good predictivity. The 2D-

09076767-060704
1020990-2979260

5

10

15

20

30

2D-fingerprints and the pharmacokinetic property. Any analytical method such as partial least square (PLS) algorithm, sample-distance partial least squares (SAMPLS; Bush, B. L. *et al. J. Computer-Aided Mol. Design*, 1993, 7, 587-619), genetic algorithm or neural network can be employed to yield an optimal quantitative structure

5 property relationship (QSPR) model.

(d) The pharmacokinetic property for trial molecules can be calculated based on the above obtained QSPR model.

The pharmacokinetic properties of the molecule such as absorption, distribution, metabolism and excretion, can be apparent permeability coefficients

10 (P_{app}) [cm/sec], blood-brain barrier partitioning ratio $\{(C_{brain}/C_{blood}) = BB\}$, half-life($T_{1/2}$) in mammalian liver microsome and the like.

The system of this invention can be constructed using appropriate computer hardware such as a Silicon Graphics OctaneTM workstation and software as described above.

15 This invention will be further described below with reference to the following Working Examples.

Examples

Example 1

20 **Development and validation of QSPR for half life in human liver microsome.**

Computational modeling studies were carried out using a Silicon Graphics OctaneTM workstation. A congeneric series of 54 compounds of Formula (I)(as shown in the following Table 1.) with a variety of substituent groups were used as a training set for analysis.

25




Table 1.

#	A	R1	R2
---	---	----	----

	1a	cycloheptyl	piperidiny1	Ph
	2a	cycloheptyl	H ₂ N(CH ₂) ₂ O-	Ph
	3a	cycloheptyl	4-aminopiperidyl	Ph
	4a	cycloheptyl	H ₂ N(CH ₂) ₂ C(O)-	Ph
5	5a	cycloheptyl	H ₂ N(CH ₂) ₂ CONH-	Ph
	6a	cyclohepten-1-yl	4-aminopiperidyl	Ph
	7a	cyclooctyl	H ₂ NCH ₂ CONH-	Ph
	8a	cycloheptyl	H ₂ N(CH ₂) ₃ -	Ph
	9a	cycloheptyl	4-aminocyclohexylamino	Ph
10	10a	cyclohepten-1-yl	piperaziny1	Ph
	11a	cycloheptyl	piperaziny1	Ph
	12a	cycloheptyl	H ₂ N(CH ₂) ₂ NH-	Ph

09876767 060701
T02090 29292660

Table 1. (continued)

#	A	R1	R2
5	13a	cycloheptyl	H ₂ NC(CH ₃) ₂ CH ₂ NH- Ph
	14a	cycloheptyl	N-methylpiperazinyl Ph
	15a	cycloheptyl	piperidinylamino Ph
	16a	cycloheptyl	4-aminopiperidyl CH ₃
	17a	cycloheptyl	piperidinyl CH ₃
10	18a	cycloheptyl	H ₂ N(CH ₂) ₁₀ NH- Ph
	19a	cycloheptyl	4-aminoazetidiny Ph
	20a	cycloheptyl	H ₂ N(CH ₂) ₈ NH- Ph
	21a	cycloheptyl	(CH ₃) ₂ N(CH ₂) ₂ NH- Ph
	22a	cyclooctyl	N-methylpiperazinyl Ph
15	23a	cycloheptyl	piperazinyl isopropyl
	24a	cycloheptyl	piperidinecarboximidamide Ph
	25a	cycloheptyl	H ₂ N(CH ₂) ₆ NH- Ph
	26a	cycloheptyl	H ₂ N(CH ₂) ₄ NH- Ph
	27a	cyclononyl	amino Ph
20	28a	cycloheptyl	CH ₃ NH(CH ₂) ₂ NH- Ph
	29a	cyclooctyl	piperazinyl CH ₃
	30a	cycloheptyl	4-aminopiperidyl vinyl
	31a	cycloheptyl	isopropyl Ph
	32a	cycloheptyl	2-guanidinoethyl Ph
25	33a	cycloheptyl	mathanesulfoonyl Ph
	34a	cycloheptyl	piperidinyloxy Ph
	35a	cycloheptyl	dimethylamino Ph
	36a	cycloheptyl	amino Ph
	37a	cycloheptyl	CH ₃ CONH- Ph
30	38a	cycloheptyl	hydroxypiperidinyl Ph
	39a	cycloheptyl	H ₂ N(CH ₂) ₃ SO ₂ - Ph
	40a	cycloheptyl	methylamino Ph
	41a	cycloheptyl	methyl Ph
	42a	cyclooctyl	piperazinyl CH ₃
35	43a	cycloheptyl	isobutyl(NH ₂)CHCONH- Ph
	44a	cycloheptyl	methylamino CH ₃
	45a	cycloheptyl	methoxy Ph
	46a	cyclooctyl	methylamino normalpropyl

09876767.060701

Table 1. (continued)

#	A	R1	R2
47a	cyclooctyl	methylamino	CH ₃
48a	cyclooctyl	methylpiperazinyl	CH ₃
5 49a	cycloheptyl	H	Ph
50a	cyclononyl	methylamino	CH ₃
51a	cyclononyl	methylpiperazinyl	CH ₃
52a	cycloheptyl	isobutyl(NH ₂)CHCONH-	CH ₃
53a	cycloheptyl	H ₂ N(CH ₂) ₂ CONH-	Ph
10 54a	cycloheptyl	H ₂ N(CH ₃) ₂ CCONH-	Ph

Half-life ($t_{1/2}$) *in vitro* for each compound was determined by HPLC analysis of the reaction mixture with human liver microsome. The employed 2D-structures were retrieved from ISISTM/Base (version 2.2.1, MDL Information Systems, Inc., San Leandro, CA) or constructed with ISISTM/Draw (version 2.2.1, MDL Information Systems, Inc., San Leandro, CA) on a WinNT client PC, followed by being transferred to the Octane workstation and stored in a molecular database. The 2D-fingerprints were constructed by use of a newly developed macro script 2dfp.spl, written in SYBYLTM Programming Language (SPL), which was implemented in SYBYLTM (version 6.5, Tripos Inc., St. Louis, MO). The macro program converted 2D-structures stored in the molecular database as MOL or MOL2 format into SYBYLTM line notation (SLN) format, and counted the number of the atoms or functional groups that matched queries defined in a table described in the macro program. The atoms or functional groups susceptible to be involved in metabolism were assigned on the basis of the literature source (Bonse, V. G., Metzler, M. "Biotransformationen Organischer Fremdstoffe" (Yakubutu-Taisya, in Japanese) Asakura, Tokyo (1980); Kato, R.; Kamataki, T. "Yakubutu-Taisyagaku" in Japanese, Tokyo-Kagaku-Dojin Tokyo (1995)). Partial least square (PLS) algorithm in QSPR module in SYBYLTM was employed to correlate the aforementioned 2D-fingerprints and $t_{1/2}$ to produce QSPR model. Thirty-eight bits out of whole 2D-fingerprints used since 25 bits with all the same value or 0 were dropped. SAMPLS run in crossvalidation step (leave-1-out) identified the optimum PLS component as 5 ($N = 54$, Std. Error_prediction = 0.414; $q^2 = 0.518$). Non-crossvalidation PLS analysis resulted in a significant five-component model with the following statistics: Std. Error_Est. = 0.219, $r^2 = 0.865$, $F(n1 = 5, n2 = 48) = 61.3$.

Figure 2 shows the plot of actual vs. calculated log $t_{1/2}$ (closed circles). For validation of the present QSPR model, the prediction of half-life for the test set (12

compounds) was performed. As indicated open squares in Figure 2, the model has a fairly good predictivity, which allows us to prioritize the targets for synthesis.

Example 2

5 Development of QSPR for Caco-2 permeability.

Unless otherwise noted similar computational molecular modeling were performed as described in Example 1. Table 2 enlists 21 structurally diverse compounds as a training set, whose apparent permeability coefficients (P_{app}) [cm/sec] of a compound across Caco-2 cells was used as in literature source (Yee, S. *Pharm. Res.* **1997**, 14, 763—766). The counts of substructures to match with the predefined queries were encoded as a array of integers by a similar SPL script (2dfp_abs.spl) to afford 2D-fingerprints as descriptors employed in the correlation analysis. SAMPLS run in crossvalidation step (leave-1-out) identified the optimum PLS component as 2 (N = 21, Std. Error_prediction = 0.444; q^2 = 0.463). Non-crossvalidation PLS analysis
 10 resulted in a significant two-component model with the following statistics: Std. Error_Est. = 0.254, r^2 = 0.824, $F(n1 = 2, n2 = 18) = 42.1$. Figure 3 shows the plot of actual vs. calculated $\log(P_{app} * 10^6)$.
 15

Table 2. Training set compounds with apparent permeability.

Compd.	$P_{app} * 10^6$ (cm/sec)	Compd.	$P_{app} * 10^6$ (cm/sec)	Compd.	$P_{app} * 10^6$ (cm/sec)
Azithromycin	1.04	Diazepam	70.97	Prazosin	43.60
Benzylpenicillins	1.96	Erythromycin	1.80	Propranolol	27.50
Caffeine	50.50	Fluconazole	29.80	Quinidine	20.40
Chloramphenicol	20.60	Ibuprofen	52.50	Tenidap	51.20
Clonidine	30.10	Imipramine	14.10	Testosterone	72.27
Desipramine	21.60	Methotrexate	1.20	Trovafloxacin	30.23
Dexamethasone	23.40	Naloxone	28.20	Ziprasidone	12.30

20

Example 3

Development of QSPR for blood-brain barrier partition.

Unless otherwise noted, similar molecular modeling was performed as described in Example 1. Blood-brain barrier partitioning ratio, $\{\log(C_{brain}/C_{blood}) = \log BB\}$ for

09876757-060701
T020900-2929860

Chart 1. Compounds employed in the analysis. (compound 36 for validation)




Chart 1(continued). Compounds employed in the analysis. (compound 36 for validation)





Chart 1(continued). Compounds employed in the analysis. (compound 36 for validation)



Example 4

SPL macro (2dfp.spl) to prepare 2D-fingerprints for half life.

```

10 uims define macro 2dfp sybylbasic yes
   ##
   ## Set the Source Database, and Column-Names File.
   ##
15 setvar source %promptif("$1" "STRING" "MYFILE.MDB" "Source Database.mdb"
   "Database with molecules to be calculated")
   setvar resultsFP %promptif("$1" "STRING" "Columns.txt" "Filename storing column
   names" "Text file to store column names")

20 ## if %not(%mols(*))
   ##      %dialog_message(ERROR "There are no molecules." "No Molecules")
   >$NULLDEV
   ##      return
   ## endif

25 #
  
```

09876767-060701

Set the molecule area to calculate "2D-FingerPrint".
Note that \$current_molarea is defined by the "calling"
table when adding a column of data.

5 localvar mol_area

if \$1
 setvar mol_area \$1
else
10 setvar mol_area \$current_molarea
endif

database open \$source read

15 ##
Loop over all molecules in the source database

for j IN %database(*)
 database get "\$j" \$mol_area
20 #
set the SLN expression for the molecular area

 setvar sln_exp %sln(\$mol_area)
 setvar ARRAY
25 #
items + 1 (compd_num) BIT's will be used

@compdnum) ##### BIT 1
30 setvar ARRAY[01] %mol_info(\$mol_area name)

Exp-Generator_read(file_ID) looping is another choice.....

Unsaturated bonds ##### BIT 2~4
35 ## fp1a) Unsaturated bonds (aromatic)
 setvar query Any:Any
 setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))

09876767 060701

setvar ARRAY[02] \$BIT
fp1b) Unsaturated bonds (bouble)
setvar query Any=Any
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
5 setvar ARRAY[03] \$BIT
fp1c) Unsaturated bonds (triple)
setvar query Any#Any
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[04] \$BIT
10 ##### ring (topology) ##### BIT 5~15
@fp2a) 3-membered ring
setvar query Hev[1]~Hev~Hev@1
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
15 setvar ARRAY[05] \$BIT
##@fp2b) 4-membered ring
setvar query Hev[1]~Hev~Hev~Hev@1
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[06] \$BIT
20 ##@fp2c) 5-membered ring
setvar query Hev[1]~Hev~Hev~Hev~Hev@1
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[07] \$BIT
##@fp2d) 6-membered ring
25 setvar query Hev[1]~Hev~Hev~Hev~Hev~Hev@1
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[08] \$BIT
##@fp2e) phenyl ring
setvar query C[1]:C:C:C:C:C:@1
30 setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[09] \$BIT
##@fp2f) 7-membered ring
setvar query Hev[1]~Hev~Hev~Hev~Hev~Hev~Hev@1
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
35 setvar ARRAY[10] \$BIT
##@fp2g) 8-membered ring
setvar query Hev[1]~Hev~Hev~Hev~Hev~Hev~Hev~Hev@1

09876767-0660701

setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[11] \$BIT
##@fp2h) 9-membered ring
setvar query Hev[1]~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev@1
5 setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[12] \$BIT
##@fp2i) 10-membered ring
setvar query Hev[1]~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev@1
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
10 setvar ARRAY[13] \$BIT
##@fp2j) 11-membered ring
setvar query Hev[1]~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev@1
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[14] \$BIT
15 ##@fp2k) 12-membered ring
setvar query
Hev[1]~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev~Hev@1
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[15] \$BIT
20 ##### Elements __Overall ##### BIT 16~22
##@fp3a) total Hetro atoms
setvar query Het
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
25 setvar ARRAY[16] \$BIT
##@fp3b) total Halogen
setvar query Any[is=F,Br,Cl,I]
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[17] \$BIT
30 ##@fp3c) total N
setvar query N
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[18] \$BIT
##@fp3d) total NH
35 setvar query NH
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[19] \$BIT

09876767 "060701

```

##@fp3e) total O
    setvar query O
    setvar BIT %count(%search2D($sln_exp $query NoDuplicate 0 yes))
    setvar ARRAY[20] $BIT
5  ##@fp3f) total OH
    setvar query OH
    setvar BIT %count(%search2D($sln_exp $query NoDuplicate 0 yes))
    setvar ARRAY[21] $BIT
##@fp3g) total S
10  setvar query S
    setvar BIT %count(%search2D($sln_exp $query NoDuplicate 0 yes))
    setvar ARRAY[22] $BIT

##### Methyl, terminal ##### BIT 23~26
15  ##@fp4a) C-Methyl (omega-Oxidation)
    setvar query C-CH3
    setvar BIT %count(%search2D($sln_exp $query NoDuplicate 0 yes))
    setvar ARRAY[23] $BIT
##@fp4b) N-Methyl (N-demethylation)
20  setvar query N-CH3
    setvar BIT %count(%search2D($sln_exp $query NoDuplicate 0 yes))
    setvar ARRAY[24] $BIT
##@fp4c) O-Methyl (O-demethylation)
    setvar query O-CH3
25  setvar BIT %count(%search2D($sln_exp $query NoDuplicate 0 yes))
    setvar ARRAY[25] $BIT
##@fp4d) S-Methyl (S-demethylation)
    setvar query CH3-S[F]-Any[NOT=H*]
    setvar BIT %count(%search2D($sln_exp $query NoDuplicate 0 yes))
30  setvar ARRAY[26] $BIT

##### Methylene -CH2- ##### BIT 27~30
##@fp5a) Methylene group
    setvar query Any[NOT=H*,N,O]-CH2-Any[NOT=H*,N,O]
35  setvar BIT %count(%search2D($sln_exp $query NoDuplicate 0 yes))
    setvar ARRAY[27] $BIT
##@fp5b) N-Methylene

```

SECRET

setvar query N-CH2-Any[NOT=H*]
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[28] \$BIT
##@fp5c) O-Methylene
5 setvar query O-CH2-Any[NOT=H*]
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[29] \$BIT
##@fp5d) S-Methylene
10 setvar query S[F]-CH2-Any[NOT=H*]
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[30] \$BIT

Methine >CH-, Allylic/Benzylic H (to be absorbed)
BIT 31~36
15 ##@fp6a) Methine group
setvar query Any[NOT=H*,N,O,S]-CH(-Any[NOT=H*,N,O,S])-
Any[NOT=H*,N,O,S]
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[31] \$BIT
20 ##@fp6b) Benzylic H (Ar-CH) (if Ph-CH2, then the count =2)
setvar query CHC(:Any):Any
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[32] \$BIT
##@fp6c) Allyl H (if CR=CR-CH2, then the count =2)
25 setvar query CHC(=C)
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[33] \$BIT
##@fp6d) N-Methine
setvar query N-CH(-Any[NOT=H*])-Any[NOT=H*]
30 setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[34] \$BIT
##@fp6e) O-Methine
setvar query O-CH(-Any[NOT=H*])-Any[NOT=H*]
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
35 setvar ARRAY[35] \$BIT
##@fp6f) S-Methine
setvar query S-CH(-Any[NOT=H*])-Any[NOT=H*]

09076767-060701

setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[36] \$BIT

Nitrogen containing Compounds ##### BIT 37~49

5 ##### Amines / Imines / Nitrile ##### BIT 37~46

##@fp7a) Primary Amines, unbranched

setvar query NH2CH2
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[37] \$BIT

10 ##@fp7b) Primary Amines, branched

setvar query NH2CH(Any[NOT=H*])(Any[NOT=H*])
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[38] \$BIT

##@fp7c) Primary Amines, branched

15 setvar query NH2C(Any[NOT=H*])(Any[NOT=H*])(Any[NOT=H*])
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[39] \$BIT

##@fp7d) Primary Anilines (Ar-NH2)

20 setvar query NH2C:Any(:Any[NOT=H*])
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[40] \$BIT

##@fp7e) Secondary Amines,

25 setvar query NH(C[NOT=C=O])C[NOT=C=O]
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[41] \$BIT

##@fp7f) Tertiary Amines

setvar query N(C[NOT=C=O])(C[NOT=C=O])(C[NOT=C=O])
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[42] \$BIT

30 ##@fp7g) Imines

setvar query N=C
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[43] \$BIT

##@fp7h) Nitrile

35 setvar query C#N
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[44] \$BIT

09876767.060701
T04090.29292860

- ##@fp7i) N in aromatics
setvar query Any[is=N,C]:N:Any[is=N,C]
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[45] \$BIT
- 5 ##@fp7j) Guanidine
setvar query NC(=N)N
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[46] \$BIT
- 10 ##### N~O, Nitro, N-N ##### BIT 47~49
##@fp7k) NO {Hydroxyamine, Oxime, Hydroxamic acid,)
setvar query N-O
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[47] \$BIT
- 15 ##@fp7l) Nitro (count =2), Nitroso (count =1)
setvar query N(=O)
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[48] \$BIT
- ##@fp7m) N~N
20 setvar query N~N
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[49] \$BIT
- ##### Amide, Ester, Sulfonamide ##### BIT 50~52
- 25 ##@fp8a) Ester
setvar query C(=O)OC
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[50] \$BIT
- ##@fp8b) Amide
30 setvar query NC(=O)
setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[51] \$BIT
- ##@fp8c) Sulfonamide
setvar query NS(=O)(=O)
35 setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))
setvar ARRAY[52] \$BIT

09876767-060701

Ketone, Aldehyde, Alcohol, Thiol, Sulfide ### BIT 53~59

##@fp9a) Primary Alcohol

setvar query CH₂(OH)(~Hev)

setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))

5 setvar ARRAY[53] \$BIT

##@fp9b) Secondary Alcohol

setvar query CH(OH)(~Hev)(~Hev)

setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))

setvar ARRAY[54] \$BIT

10 ##@fp9c) Ketone, Aldehyde

setvar query Any[is=H,C]CC(=O)(Any[is=H,C])

setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))

setvar ARRAY[55] \$BIT

##@fp9d) COOH

15 setvar query Any[is=H,C]CC(=O)(OH)

setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))

setvar ARRAY[56] \$BIT

##@fp9e) Sulfide

setvar query CS[F]C

20 setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))

setvar ARRAY[57] \$BIT

##@fp9f) Thiol

setvar query S[F]H(C)

setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))

25 setvar ARRAY[58] \$BIT

##@fp9g) Thiocarbonyl

setvar query C=S

setvar BIT %count(%search2D(\$sln_exp \$query NoDuplicate 0 yes))

setvar ARRAY[59] \$BIT

30

echo \$ARRAY

echo \$ARRAY >> \$resultsFP

zap \$mol_area

35 endfor

database close

09076767.060701

##

Announce of the completion & the location of the results

echo

echo "job completed on %system(date)"

5 echo "The results is stored \$resultsFP as a text file,"

echo "please import if from MSS (table)."

echo " ==> custom format, space separated, column label used"

10

Example 5

By use of a similar method described in example 4, 2D-Fingerprints for Caco-2 permeability and blood-brain barrier partition were prepared based on the following description.

15

Fp-ID	Name	Query
<u>Alkyl Amines</u>		
fp1a	Primary	NH2C[NOT=C=O,C=S,C:Any,Any[IS=C,N]C(=N)N,C[1](Any[IS=O,S,N]Any=:AnyAny=@1),C[1](=AnyAny[IS=O,S,N]Any=:Any@1)]
fp1b	Secondary	NH(C[NOT=C=O,C=S,C:Any,Any[IS=C,N]C(=N)N,C[1](Any[IS=O,S,N]Any=:AnyAny=@1),C[1](=AnyAny[IS=O,S,N]Any=:Any@1)))(C[NOT=C=O,C=S,C:Any,Any[IS=C,N]C(=N)N,C[1](Any[IS=O,S,N]Any=:AnyAny=@1),C[1](=AnyAny[IS=O,S,N]Any=:Any@1))
fp1c	Tertiary	N(C[NOT=C=O,C=S,C:Any,Any[IS=C,N]C(=N)N,C[1](Any[IS=O,S,N]Any=:AnyAny=@1),C[1](=AnyAny[IS=O,S,N]Any=:Any@1)))(C[NOT=C=O,C=S,C:Any,Any[IS=C,N]C(=N)N,C[1](Any[IS=O,S,N]Any=:AnyAny=@1),C[1](=AnyAny[IS=O,S,N]Any=:Any@1)))(C[NOT=C=O,C=S,C:Any,Any[IS=C,N]C(=N)N,C[1](Any[IS=O,S,N]Any=:AnyAny=@1),C[1](=AnyAny[IS=O,S,N]Any=:Any@1))
<u>Amines attached to heteroaromatics</u>		
fp2a	Primary	C[1](Any[IS=O,S,N]Any=:AnyAny=@1)NH2 C[1](=AnyAny[IS=O,S,N]Any=:Any@1)NH2
fp2b	Secondary	C[1](Any[IS=O,S,N]Any=:AnyAny=@1)NHAny[NOT=H*] C[1](=AnyAny[IS=O,S,N]Any=:Any@1)NHAny[NOT=H*]
fp2c	Tertiary	C[1](Any[IS=O,S,N]Any=:AnyAny=@1)N(Any[NOT=H*])Any[NOT=H*] C[1](=AnyAny[IS=O,S,N]Any=:Any@1)N(Any[NOT=H*])Any[NOT=H*]
<u>Anilines</u>		
fp3a	Primary	NH2C(:Any)(:Any[NOT=H*])
fp3b	Secondary	NH(C(:Any)(:Any[NOT=H*]))Any[NOT=H*]
fp3c	Tertiary	N(C(:Any)(:Any[NOT=H*]))(Any[NOT=H*])Any[NOT=H*] N(C(:Any)(:Any[NOT=H*]))=C

09876767 060701

N in aromatics

fp4a	6-membered ring	Any[is=N,C]:N:Any[is=N,C]
fp4b	-NH- in heteroaromatics	N[1]HAny[IS=C,N]=:Any[IS=C,N]Any[IS=C,N]=:Any[IS=C,N]-@1
fp4c	-N- in heteroaromatics	N[1]Any[IS=C,N]=:Any[IS=C,N]Any[IS=C,N]=:Any[IS=C,N]-@1
fp4d	-N= in heteroaromatics	N[1](Any[IS=O,S,N]Any=:AnyAny=@1) N[1](=AnyAny[IS=O,S,N]Any=:Any@1)

Imines/ Nitrile/ Guanidine/ Amidine

fp5a	Imines	Any[IS=C,H,S]N[NOT=N[1](Any[IS=O,S,N]Any=:AnyAny=@1),N[1](=AnyAny[IS=O,S,N]Any=:Any@1)]=C[NOT=Any[IS=C,N]C(=N)N]
fp5b	Nitrile	C#N
fp5c	Guanidine	N[NOT=C[1](Any[IS=O,S,N]Any=:AnyAny=@1)N,C[1](=AnyAny[IS=O,S,N]Any=:Any@1)N]C(=N)N[NOT=C[1](Any[IS=O,S,N]Any=:AnyAny=@1)N,C[1](=AnyAny[IS=O,S,N]Any=:Any@1)N]
fp5d	Amidine (not heteroaromatics)	Any[NOT=N]C(=N[NOT=N[1](Any[IS=O,S,N]Any=:AnyAny=@1),N[1](=AnyAny[IS=O,S,N]Any=:Any@1)])N

N~O/ Nitro/ N=N/ N-N

fp6a	Hydroxyamine, Oxime, Hydroxamic acid...	N[!r]-O[!r]
fp6b	Nitro, Nitroso	N(=O)
fp6c	N=N Azo (not in a ring)	N=N[NOT=N[1](Any[IS=O,S,N]Any=:AnyAny=@1),N[1](=AnyAny[IS=O,S,N]Any=:Any@1)]
fp6d	N-N Hydrazine	N-N[NOT=N[1](Any[IS=O,S,N]Any=:AnyAny=@1),N[1](=AnyAny[IS=O,S,N]Any=:Any@1)]

Amide/ Thioamide/ Sulfonamide

fp7a	Amide1 (NH ₂ -CO)	NH ₂ C=O
fp7b	Amide2 (R ₁ -NH-CO)	Any[NOT=H*]NHC=O
fp7c	Amide3 (R ₁ R ₂ N-CO)	Any[NOT=H*]N(C=O) Any[NOT=H*]
fp7d	Thioamide1 (NH ₂ -CS)	NH ₂ C=S
fp7e	Thioamide2 (R ₁ -NH-CS)	Any[NOT=H*]NHC=S
fp7f	Thioamide3 (R ₁ R ₂ N-CS)	Any[NOT=H*]N(C=S)Any[NOT=H*]
fp7g	Sulf.amide1 (NH ₂ SO ₂)	NH ₂ S(=O)(=O)
fp7h	Sulf.amide2 (R ₁ -NH-SO ₂)	NH(S(=O)=O)Any[NOT=H*]
fp7i	Sulf.amide3 (R ₁ R ₂ -NSO ₂)	N(S(=O)=O)(Any[NOT=H*])Any[NOT=H*]

Alcohol/ Ether/ Aldehyde/ Ketone/ Ester/ Carboxylic acid/ Carbothioic acid/ Sulfinic***acid/ Sulfonic acid***

fp8a	Alcohol	C[NOT=C=O,C=S](OH)
fp8b	Ether	Any[NOT=C=O, H*]-O-Any[NOT=C=O,H*]
fp8c	Aldehyde	CCH(=O)
fp8d	Ketone	CC(=O)C
fp8e	Ester	C(=O)OC
fp8f	Carboxylic acid	C(=O)(OH)
fp8g	Carbothioic O acid	C(=S)(OH)
fp8h	Carbothioic S acid	C(=O)(SH)
fp8i	sulfinic acid	Any[is=H,C]S[NOT=S(=O)(=O)] (=O)(OH)
fp8j	sulfonic acid	Any[is=H,C]S(=O)(=O)(OH)

09876767 "060701

Halogen		
fp9a	Fluoro	F
fp9b	Chloro	Cl
fp9c	Bromo	Br
fp9d	Iodo	I
<u>Total C/ H/ N/ O/ S</u>		
fp10a	total C	C
fp10b	total H	H
fp10c	total N	N
fp10d	total O	O
fp10e	total S	S

09876767.060701